



DISPLAY ADJUSTMENT

Tools Required

10 & 11mm Wrench
5/32" Allen Wrench

Hand Angle Adjustment

Step 1: Loosen (A)
Step 2: Rotate (A2) hands for desired location
Step 3: Tighten (A)

NOTE: We suggest making the adjustments with your gloves on the hands. This will help with making the correct graphic alignments.

Moving Hands on Wishbone™

Step 1: Remove (A)
Step 2: Remove (A2)
Step 3: Remove (B)
Step 4: Remove (C) Bolt
Step 5: Place bolt into hole (D)
Step 6: Replace all hardware as removed.

NOTE: This adjustment may need to be made for smaller gloves and better graphical alignment.

STAND ASSEMBLY

Tools Required

10 & 11mm Wrench
5/32" Allen Wrench

Assembly

Step 1: Remove protective film if applied
Step 2: Place upright (A) into base (B) slot
Step 3: Tighten

Optional: one single drop of super glue from the bottom side of stand will not allow part to be taken apart.

Glove Display attachment

Step 1: Bolt from back through upright
Step 2: Spacer on bolt and tighten firmly
Step 3: Place F3 Glove Display (C) on bolt
Step 4: Apply acorn nut to secure display
Step 5: Enjoy your gloves as they should be!
Step 6: Ask all family members to come see your new glove display!

NOTE: Made from acrylic plastic, never over tighten.

Thank you for choosing the F3 GameDay Glove Display!
The absolute best way to display your favorite graphic gloves.
Please feel free to share with us!